PX-11.409

TABLE 6-14

SET-UP OF FUNCTION TABLES* FOR PROGRAMMING TRANSMISSION OF CONSTANTS

	FUNCTION TABLE 1															FUNCTION TABLE 2															FUNCTION TABLE 3						
Arg. \ Load	PM1	A5	A6	A7	A8	A9	A10	B5	B6	B7	B8	B9	B10	PM2	PM1	A5	A6	A7	A8	A9	A10	B5	B6	B7	B8	B9	B10	PM2	PM1	A5	A6	A7	A8	A9	A10
0		9															9																		
1																		9															9		
2	M																																		
3		9															9																		
4	M	9																																	
5																		9															9		
6																	9	9																	
7 etc.																																			
Use	←																	Transmit																	→ Replace
	x_{11}	x_{11} x_{22}	x_{12}	x_{13}	x_{13}	x_{14}	x_{15}	x_{21}	x_{21}	x_{23}	x_{23}	x_{24}	x_{25}	x_{31}	x_{31}	x_{32}	x_{33}	x_{33} x_{44}	x_{34}	x_{35}	x_{41}	x_{41}	x_{42}	x_{43}	x_{43}	x_{45}	x_{51}	x_{51}	x_{52}	x_{53}	x_{53}	x_{54}	x_{55}	x_{15} by x_{53} in sec. 6R	x_{42} in sec. 7L by x_{35} in sec. 7R
(i) immediately or (d) with one add. time delay	i	d	d	i	d	d	i	i	d	i	d	d	i	i	d	d	i	d	d	i	i	d	d	d	d	i	i	d	d	i	d	d	i		
Program line used for signal	3-2	3-3	3-4	3-5	3-6	3-7	3-8	3-9	3-10	3-11	4-1	4-2	4-3	3-3	4-5	4-6	4-7	4-8	4-9	4-10	4-11	5-1	5-2	5-3	5-4	4-5	5-6	5-7	5-8	5-9	5-10	5-11	6-1	6-2	6-4

* It is assumed here that the function tables have been modified for the storage of programming data as suggested in Sec. 7.4. Furthermore, an adaptor is used at the function output terminals to take information from digit terminals to program terminals.

MINN. C.A. 4-6

PLAINTIFF'S EXHIBIT No. 22

01545