

Item	Position	Qty	Spring Comb.	Mounting	Mounting Data	Part No.	Part No.	Part No.	Part No.	Part No.	Part No.	Part No.	Part No.	Part No.	Part No.
Item 1	A	U	111/101 3 Holes	1 1/4	Printer Relay Hood				.0043	.0046	.0003	.0004	.0005	.0006	.0007
Item 2	A-1	U	111/111 4 Holes		Relay Hood				.0044	.0047	.0011	.0012	.0013	.0014	.0015
Item 3	Carry	U	111/101 IMAX-7280K		700				.0118	.0125	.0011	.0012	.0013	.0014	.0015
Item 4	B	U	139/114 5 Holes 1 Hole on each	1 3/4	Relay Hood				.0105	.0111	.0021	.0022	.0023	.0024	.0025
Item 5	C	Form. V	101/101 2 Holes	1 1/4	Rel. - 6450T #300 350 Sec. - 6700T #300 1150T				.010	.009	.0017	.0018	.0019	.0020	.0021
Item 6	CR	UK 1/4 Coax .083 Arm	111/101 3 Holes on each	1 1/4	5900T #300 1150T				.005	.009	.0015	.0016	.0017	.0018	.0019
Item 7	FM	Form. U	120/110 3 Holes 2 Holes on each	1 3/4	Rel. - 3400T #300 350 Sec. - 6700T #300 1150T				.005	.009	.0016	.0017	.0018	.0019	.0020
Item 8	GR	Form. J	101/101 2 Holes	1 1/4	Relay Hood				.010	.009	.0017	.0018	.0019	.0020	.0021

\* Resistance 1 ohm, 20% resistance per relay.

Item	Printer	Description	Part No.	Part No.	Part No.	Part No.
Item 1	Printer	U type relay hood chms Coil assembly per Armature assembly per Armature hinge bracket per Spring comb. 111/101 Contact metal Heavy #2 (Form 243) Adjustment: Armature travel .002 Operate .005 Release .003	LP46642 LP46616 LP46606			
Item 2	Printer	U type relay hood chms Coil assembly per Armature assembly per Armature hinge bracket per Spring comb. 111/111 Contact metal Heavy #2 (Form 243) Adjustment: Armature travel .003 Operate .005 Release .001	LP46642 LP46616 LP46606			
Item 3	Printer	U type relay hood chms Coil assembly per Armature assembly per Armature hinge bracket per Spring comb. 111/101 Contact metal Heavy #2 (Form 243) Adjustment: Armature travel .005 Operate .005 Release .001	LP46642 LP46616 LP46606			
Item 4	Printer	U type relay hood chms Coil assembly per Armature assembly per Armature hinge bracket per Spring comb. 139/114 Contact metal Heavy #2 (Form 243) Adjustment: Armature travel .009 Operate .011 Release .002	LP46642 LP46616 LP46606			

Item	Transmitter	Description	Part No.	Part No.	Part No.	Part No.
Item 5	Transmitter	Parasilly U type Pri. 350 ohm Sec. 1150 ohm Coil assembly per Armature assembly per Armature hinge bracket per Spring comb. 111/101 Contact metal Heavy #2 (Form 243) Adjustment: Armature travel .002 Operate .005 Release .003	LP46642 LP46616 LP46606			
Item 6	Transmitter	U type relay hood chms Coil assembly per Armature assembly per Armature hinge bracket per Spring comb. 111/101 Contact metal Heavy #2 (Form 243) Adjustment: Armature travel .003 Operate .005 Release .001	LP46642 LP46616 LP46606			
Item 7	Transmitter	U type relay hood chms Coil assembly per Armature assembly per Armature hinge bracket per Spring comb. 100/114 Contact metal Heavy #2 (Form 243) Adjustment: Armature travel .003 Operate .005 Release .001	LP46642 LP46616 LP46606			
Item 8	Transmitter	U type relay hood chms Coil assembly per Armature assembly per Armature hinge bracket per Spring comb. 111/101 Contact metal Heavy #2 (Form 243) Adjustment: Armature travel .003 Operate .005 Release .001	LP46642 LP46616 LP46606			

Item	Relay	Description	Part No.	Part No.	Part No.
Item 9	Relay	15L-AG resistor			
Item 10	Relay	15L-AG resistor			
Item 11	Relay	15L-AG resistor			
Item 12	Relay	15L-AG resistor			
Item 13	Relay	15L-AG resistor			
Item 14	Relay	15L-AG resistor			
Item 15	Relay	15L-AG resistor			