


No Load Box is used on this tray which carries pulses for the answer. No other units are to be connected into it.



ITEM	DESCRIPTION	REFER TO
ST ₁ SU ₁	ACCUMULATOR INTERCONNECTOR TERMINALS	PX-5-105
SU ₂ SU ₃ SV	DIVIDER & SQUARE ROOTER PROGRAMMING TERMINALS	PX-10-108
d	SPECIAL CABLE FROM DIGIT TRAY TO ST ₁ & SU ₁ ON QUOTIENT ACC.	PX-5-134
b c	ADAPTORS FROM SU ₂ TO DIGIT TRAY OR FROM SU ₃ TO DIGIT TRAY	{ PX-4-114A, A & AC ADAPTOR PX-4-114B, A & S ADAPTOR PX-4-114C, AC & SC ADAPTOR
d	SPECIAL CABLE FROM DIGIT TRAY TO ST ₁ & SU ₁ ON THE DENOM. & SQ. ROOT ACC.	PX-5-136
l	SPECIAL CABLE FROM DIGIT TRAY TO ST ₁ & SU ₁ ON THE SHIFT ACC.	PX-5-135
f	SPECIAL CABLE FROM SV TO ST ₁ & SU ₁ ON THE NUMERATOR ACC.	PX-5-137

MOORE SCHOOL OF ELECTRICAL ENGINEERING
UNIVERSITY OF PENNSYLVANIA

INTERCONNECTION OF DIVIDER & SQUARE ROOTER WITH
ASSOCIATED ACCUMULATORS ~ PX-10-307

MINN. CA. 487 CIV. 138
PLANTERS TRIAL
EXHIBIT
No. 22363