



TERMINALS 11, 21, ..., 301  
 Program input pulse terminals associated respectively with constant selector switches 1-30.

TERMINALS 10, 20, ..., 300  
 Program output pulse terminals associated respectively with constant selector switches 1-30.