


PLUG BOARD FOR GANG PUNCH



USE OF THE EMITTER OUTPUT HUBS AND COMMON TERMINALS

Line a: A zero punch is to be made in column 61.

Lines b,c,d,e,f: A 12 punch (b) is to be made in columns 20 (c), 40 (d), 60 (e), and 80 (f).

IBM GANG PUNCH
 Plug Board
 PX-12-305R2