



(1-6)-SELECTIVE CLEAR TRANSCIVER NEONS

FRONT PANEL

- 7- READER (R) & PRINTER (P) START NEONS
- 8- F- READER FINISH NEON
- I- READER INTERLOCK NEON
- 9- READER SYNCHRONIZING (S) NEON
- 10- F- PRINTER FINISH NEON
- S- PRINTER SYNCHRONIZING NEON
- 11- I- INITIATING PULSE INPUT NEON
- S- I. P. SYNCHRONIZING NEON

PROGRAM TRAYS

07 0 242